

A guide to

port forwarding



Port forwarding allows remote computers to connect to a specific device or service within a private local area network (LAN).

To set up port forwarding on your Home Hub, simply follow the steps below.


- 1 Open your browser and type in the following address:

http://192.168.0.1


When asked, enter the following credentials:

Login: admin


Password: optify



- 2 On the menu on the left, click on **Configuration**.



- 3 On the new menu that appears, click on **Firewall**, then **Port Forwarding**.



④ From here you can configure the port forwarding you need:

Name:

Enter a name for your new rule. It can be anything you like.

Type:

Pick **Range** for a port range, **DMZ** for all ports or **Remap** to change a port number for an IP address

Port Start:

Enter the starting port number

Port End:

Enter the last port number to forward

Protocol:

Select traffic protocol (**UDP/TCP/Both**)

NAT Interface:

Select WAN interface (eth0 by default)

Private IP Address:

Enter the IP address of the device

Click **Add rule**

http://192.168.0.1

System

Configuration

- System Info
- Static Route
- Access Control
- Firewall
 - Global
 - Mgmt Access
 - Port Forwarding
- Interfaces
 - L2CP
 - LLDP-MED
 - RIP
 - Parental Control
- Wireless
 - Voice
 - VLAN
 - WAN Backup

Configuration - Firewall Port Forwarding

Port Forwarding Rules

Name:

Type:

Port Start: Port End:

Protocol:

NAT Interface:

Private IP Address:

Name	Type	Port Start	Port End	Protocol	NAT Interface	Private IP	Private Port	Delete
tst	Range	9909	9909	TCP	eth0.v101	192.168.0.10		

- 5 If you want to remove a port forwarding rule, just check the box in the **Delete** column and then click **Delete rule(s)**.

http://192.168.0.1

System

Configuration

- System Info
- Static Route
- Access Control
- Firewall
 - Global
 - Mgmt Access
 - Port Forwarding
- Interfaces
- L2CP
- LLDP-MED
- RIP
- Parental Control
- Wireless
- Voice
- VLAN
- WAN Backup

Configuration - Firewall Port Forwarding

Port Forwarding Rules

Name:

Type:

Port Start: Port End:

Protocol:

NAT Interface:

Private IP Address:

Add Rule

Name	Type	Port Start	Port End	Protocol	NAT Interface	Private IP	Private Port	Delete
tst	Range	9909	9909	TCP	eth0.v101	192.168.0.10		<input type="checkbox"/>

Delete rule(s)

All done

Your Home Hub should now be passing data correctly to your devices.